



High-Volume Jet Pump Standard Circulation and Reverse Circulation

The Bottom Hole Assembly includes the porting to allow for maximum production and lift capacity. This pump can be set up as a free type standard circulation pump for ease of installation and retrieval. The High-Volume jet pump can also be installed as reverse circulation with the use of a locking mandrel at the top of the pump to hold it in place during operation, and can be installed and retrieved using wireline tools.

